


AR502 Instruction

1. Face Plate Sketch

Actual size



Accessories :

- extra fuse,
- (4) mounting screws, star washer and nuts for front panel mount
- Serial # sticker

Driver and Co-Driver

Pin1 : MIC -
 Pin2 : PTT
 Pin3 : MIC +
 Pin4 : SPK +
 Pin5 : SPK -

Radio

Pin1 : GND (floated)
 Pin2 : PTT
 Pin3 : Sig Out to Radio
 Pin4 : Sig In+ from Radio
 Pin5 : Sig. In- from Radio

Driver and Co-Driver PTT

Pin1 : GND
 Pin2 : NC
 Pin3 : PTT +